

Main Injector Note #0191
8 GeV Line Instrumentation: Locations and Rack Layouts
G. Vogel 10/29/96

This note is intended to provide information on the installation locations for the 8 GeV transfer line diagnostics, both detectors and electronics. The electronics for the 8 GeV line will be divided between three service buildings, MI-10, MI-8 and the Booster West tower. In order to accomodate the required 8 GeV systems (vacuum, correctors, diagnostics, etc.) a new row of four relay racks will be installed in Booster West facing the G04-RR1 group. They will be designated G04-RR0-xx.

Beam Loss Monitors (BLMs)

There are 67 BLMs spaced along the 8 GeV transfer line. 35 are cabled back to the Booster West tower BPM/BLM instrumentation rack (G04-RR1-5), the other 32 are cabled to the MI-8 service building CR (MI8117).

Beam Position Monitors (BPMs)

There are 59 BPMs associated with the 8 GeV line, 54 single-plane, split-plate detectors and 5 dual-plane stripline detectors. The 5 dual-plane detectors and 18 of the single-plane units are cabled to Booster West with the remaining 36 detectors being cabled to MI-8 (MI8117/6).

Toroids

There are two toroids in the 8 GeV line, One at the "top" of the line near VBC1 and one at the "bottom" of the line downstream of Q852. The toroid at VBC1 is already installed, while the unit at Q852 will be cabled to MI-10 (MI10117). The downstream toroid will be temporarily installed downstream of Q832 and cabled to MI-8 (MI8118) for the initial 8 GeV line testing.

Multiwires

There are 14 positions for multiwires in the 8 GeV line. They are located near the following quads; 800, 801, 810, 811, 813, 814, 825, 826, 830, 836, 839, 840, 851 and 852. At present it is expected that not all positions will be permanently populated. The systems for Q800 and Q801 are already installed. The units for Q810-Q814 will be cabled to Booster West (G04-RR0-4), units for Q825-Q840 will be cabled to the MI-8 CR (MI8118) and the remaining units (Q851 & Q852) will be cabled to the MI-10 CR (MI10117). The multiwire for Q836 will be temporarily installed at Q832 for initial 8 GeV line testing.


8-GeV Detector Cable List

	Detector	Detector Location	Electronics Location	Cabling (per detector)
8 GeV Line Detectors				
Multiwires	Q800, Q801	Booster Gallery	2 - 26C bundle RG174; 1 - 10C#22	
	Q810, Q811, Q813, Q814	Booster West Rack G04-RR0-4	2 - 26C bundle RG174; 1 - 10C#22	
	Q825, Q826, Q830 Q836, Q839, Q840	MI-8 CR; Rack #MI8118	2 - 26C bundle RG174; 1 - 10C#22	
	Q851, Q852	MI-10 CR; Rack #MI10117	2 - 26C bundle RG174; 1 - 10C#22	
Upstream Toroid	VBC1	Booster Gallery	1 - 3/8" Heliax; 1 - RG58	
Downstream Toroid	Q852 (Temp. Q832)	Booster West Rack G04-RR0-4 (MI-8 CR; Rack #MI8118)	1 - 3/8" Heliax; 1 - RG58	
BLMs	Q800-Q822 (35)	Booster West Rack G04-RR1-5	1 - RG58; 1 - RG58 RED	
	Q823-Q852 (32)	MI-8 CR; Rack #MI8117	1 - RG58; 1 - RG58 RED	
BPMs	Q800-Q816	Booster West Rack G04-RR1-5	2 - RG8	
	Q817-Q852	MI-8 CR; Rack #MI8116/#MI8117	2 - RG8	

MI8118

MI8117

MI8116



Main Injector MI-8 Instrumentation Rack Layout

← STORAGE ROOM

POWER SUPPLIES

Power Supply	MI8119 Unassign.	MI8118 Multiplexer BPM	MI8117 BPM	MI8116 Unassign.	MI8115 Vacuum	MI8114 Unassign.	MI8113 Corr. Element	MI8112 4H	MI8111 Corr. Element
4H	4H	4H	4H	4H	4H	4H	4H	4H	4H

Network	MI8101 Controls Links	MI8102 CATV	MI8103 Unassign.	MI8104 Unassign.	MI8105 Controls	MI8106 Unassign.	MI8107 Unassign.	MI8108 6H	MI8109 LCW	MI8110 Safety
6H	6H	4H	6H	6H	6HF	6H	6H	6HF	6H	6H

O O O O O O O O O O


COMM DUCT

EQUIPMENT ROOM



RACK ALLOCATION FOR MI-8 EQUIPMENT ROOM
JUNE 1996

Main Injector BW Instrumentation Rack Layout



Booster West High Bay Area

8 GeV Multiwire	Unassigned	Vacuum	8 GeV Correctors
G04-RR0-4	G04-RR0-3	G04-RR0-2	G04-RR0-1

Central Aisle

Outside Wall

Existing Rack to be Removed	8 GeV BPM//BLM	G04-RR1-5	G04-RR1-4	G04-RR1-3	G04-RR1-2	G04-RR1-1
-----------------------------------	-------------------	-----------	-----------	-----------	-----------	-----------

Main Injector Instrumentation Racks in Booster West