Collider Run II Shot Setup Documentation

Created by Brian Drendel 3-24-04

Last Edit by Brian Drendel 4-5-05

Send suggestions and comments to ad-pbar-tuning-adminNOSPAM@fnal.gov (remove "NOSPAM")


Sequencer: Pbar

Collider Aggregate: Run II Load Collider Pbars
Previous Aggregate: Run II Prepare to Load Pbars

Purpose of this Aggregate:

How to get back to stacking form here: Finish this aggregate and then run both the $\underline{\text{Run II Revert to Stack Lattice}}$ and the $\underline{\text{Run II}}$ Return to Stacking aggregates.

::: ACKNOWLEDGE



::: SHOT LOG COMMENT

Enters the following comment into the Pbar portion of the shot scapbook at http://www-bd.fnal.gov/cgi-mach/machlog.pl?nb=scrap03.

■ Time- Loading Pbars. The starting Stack size is 161.1875. - Sequencer

::: SHOT_LOG COMMENT

Enters the following comment into the Pbar portion of the shot scapbook at http://www-bd.fnal.gov/cgi-mach/machlog.pl?nb=scrap03.

Time- MI data for Pbars. - Sequencer

Loads TLG #18.

::: WAIT_DEVICE G:TLGSEQ

Waits for the timeline to be loaded.

::: INSTRUCT 250

Make sure that TLG file #3 is loaded before proceeding. This is the Unstack & Transfer Pbars file. For Mixed Pbars use TLG #18.

In the case of transfers to the Recycler, use #22 instead.

Interrupt anywhere in this box to continue.

```
Restart measurement on VSA.
::: SET_DEVICE A:VSALER =1.4
     Sets the VSA longitudinal emittance request in units of eV-S.
::: SET_SEQ FILE 86
     File #86 checks the SEM grid positions
     D:SM926 STATUS COMPARE off
                                                                     ok
     D:SM921 STATUS COMPARE off
d:sm917 STATUS COMPARE on
D:SM917 STATUS COMPARE off
D:SM913 STATUS COMPARE off
D:SM909 STATUS COMPARE off
D:SM906 STATUS COMPARE off
                                                                     ok
                                                                     ok
                                                                     ok
                                                                     ok
                                                                     ok
                                                                     ok
     d:sm900 STATUS COMPARE
     d:sm900 STATUS COMPARE on D:SM900 STATUS COMPARE off
                                                                     ok
::: CHECK_DEVICE A:ESHTST READING .
     Verifies that the Accumulator extraction shutter is open (A:ESHTST = 1).
::: CHECK DEVICE A: ISHTST READING .
     Verifies that the Accumulator injection shutter is open (A:ESHTST = 1).
::: CHECK_DEVICE A:EKIKTG READING .
     Verifies that the Accumulator extraction kicker start timer is set to and
     MIBS value of 13.58491 MI revolutions.
::: SET_SEQ FILE 84
     File #84 CW RF gated for shots
     A:R2LLT1 SET DEVICE 24
                                                                     ok
     A:R2LLT1 SET TIMER REFER
                                                                     ok
     A:R2LLT2 SET DEVICE
                                                                     ok
     A:R2LLT2 SET TIMER REFER
                                                                     ok
     A:R2LLT2 TURN DEVICE ON
                                                                     ok
     A:R1HLSC DIG ALARM ENABLE
                                                                     ok
     A:R4HLSC DIG_ALARM ENABLE
                                                                     ok
::: SETIT DEVICE A:R4LLAM =0
     Sets ARF4 amplitude control parameter to zero.
::: CTLIT_DEVICE A:R4HLSC ON .
     Turns on ARF4 HLRF.
::: CTLIT_DEVICE A:R4LLAM ON .
     Turns on ARF4 amplitude control.
::: CTLIT_DEVICE A:R1HLSC ON .
     Turns ARF1 HLRF on.
::: CTLIT_DEVICE A:EKIK ON
     Turns on the Accumulator extraction kicker.
::: CTLIT DEVICE A:EKIKQ ON D
     Turns on the Accumulator extraction kicker.
::: CHECK_DEVICE A:R3SPRD OFF
     Turns off the AFR3 Beam Spread enable parameter.
::: CTLIT_DEVICE A:RLLEXF ON
     Turns on the ARF4 extraction orbit frequency parameter.
::: CTLIT_DEVICE A:R4MIPS ON
     Turns on the ARF4 to Main Injector phase set point parameter.
::: SETIT_DEVICE A:R4BKMP -553 D
::: SETIT_DEVICE A:RCBKHD =10
::: EVENT 7A ENABLE
     Enables TCLK event $7A (Main Injector BPM write profile mem).
::: EVENT 94 ENABLE
     Enables TCLK event $94 (Accumulator injected pbar synch).
::: EVENT 9A ENABLE
    Enables TCLK event $91 (Accumulator Pbar to Main Injector transfer prep).
::: INSTRUCT 252
```

```
The VSA display should be running on the 'SC' window. The RF plot is about to start on the 'SB' window. Select the 'SA' window when prompted to begin the Transfer efficiency (Shoot) plot.

Interrupt anywhere in this box to continue.
```

```
::: FTP RF 0
::: FTP Shot 0
```

Starts a FTP on the screen of the operator's choice that contains Accumulator RF unstacking parameters.

- Accululator LLRF Synth #1 parameter A:RFDDS1 (628700-628950 Hz).
- ARF4 Cavity Volts parameter A:R4HLFB from 0-1500 V.
- ARF4 MI phase error parameter A:R4MIPE from -10 10 degrees
- ARF1 fanback voltage parameter A:R1FANB from 0-60 KV.
- All over time from 0-24 seconds triggered on an event \$91.

::: LOOP BEGIN: LOAD USER

Starts the "Load" loop. The loop starts from this location and ends when the sequencer LOOP END: Load command is reached.

- USER option presents the user with a dialog box that asks how many times to run the loop. The loop should be run one time for each transfer from the Accumulator. For example, if 6 of the 9 transfers come from the Accumulator, then the Pbar Sequencer Operator would enter 6.
- Which transfers come from the Recycler and which transfers come from the Accumulator are determined by the T:PBXFR array as seen on P38 MCBINNI < 8>.
- Each loop iteration performs all of the necessary steps to extract 4 groups of 2.5MHz bunches to the Main Injector.
- The loop pauses on each Recycler transfer.
- The loop repeats once for each Accumulator transfer.

```
::: WAIT_DEVICE V:TSHOOT
```

Waits for state V:TSHOOT to be 3 (ready for pbars).

```
::: SET_DEVICE A:SHTNUM +=1
```

Increments the Pbar Transfer Series shot number by one.

```
::: AUTO PLOT Shoot
```

Starts a FTP on the screen of the operator's choice to plot unstacking transfer efficiencies.

- Main Injector DCCT beam intensity readback I:IBEAMM from 0-0.32E12
- AP1 toroid beam intensity readback M:TOR105 from 0 25E10.
- AP3 toroid beam intensity readback M:TOR910 from 0 25E10.
- Accumulator DCCT beam intensity readback A: IBEAMB from stack size stack size - 25 e10.
- ullet All plotted over a time of 0-10 seconds triggered on an event \$9A.

```
::: CUSTOM UNSTACK_FRACTION
```

This command allows the operator to enter, from the data on the shot spreadsheet, the unstacking fraction. This command changes the parameter A:BMFRAC (dbeam_fraction) to "how much beam to unstuck"/A:IBEAMB.

```
::: WAIT_DEVICE A:VSAAVG
```

Waits for A: VSAAVG (VSA #1 # of averages counter) to be 1.

::: CHECK_DEVICE A:BMFRAC SETTING .


Checks the unstacking beam fraction.

::: SETIT_DEVICE A:VSAMRK =7

Sets VSA #1 marker parameter to 7.

```
::: INSTRUCT 254
      If necessary, wait here until there is confirmation that the Main
      Injector is ready for the next Pbar transfer.
                   Interrupt anywhere in this box to continue.
::: ACKNOWLEDGE
       VSA makers okay? Else change
                OΚ
                        Cancel
   SETIT_DEVICE A:VSAMRK =0
     Sets VSA #1 marker parameter to 0, and then checks that it is at that
::: CHECK DEVICE A:FLOWPC SETTING
     Checks value of A:FLOWPC (df_lower_pc) value in Hz.
::: CHECK_DEVICE A:FUPPC SETTING
     Checks value of A:FUPPC (df_uppoer_pc) value in Hz.
::: CHECK_DEVICE A:CENFRQ READING .
     Checks value of the Accumulator center revolution frequency.
::: SET DEVICE A:CNFROU A:CENFRO
     Sets A: CNFROU (Accumulator Center Revolution Frequency unstacking)
     equal to A:CENFRQ (Accumulator center revolution frequency).
::: SET DEVICE V:PBXFER V:XFER
     Sets V:PBXFER (next Pbar transfer number) equal to V:XFER (next Tev
     transfer number).
::: CHECK DEVICE A:R2DDS1 READING
     Checks the Accumulator LLRF Synth #1/h parameter setting.
::: CHECK_DEVICE D:HT901 SETTING
     Checks the setting of D:HT901.
::: WAIT_DEVICE A:R4RDY
     Waits for A:R4RDY (ARF4 ready to run) to be equal to 1.
::: CHECK DEVICE D:PERMIT ON
     Verifies that the Pbar beam permit is on.
::: EVENT 91 ENABLE
     Enables TCLK event $91 (Accumulator unstuck cycle reset).
::: WAIT_FOR EVENT 91
     Waits for the next TCLK event $91.
::: SETIT DEVICE V:PSHOOT =3
     Sets state V:PSHOOT to 3 (Unstacking Pbars to the Tevatron), and then
     checks that it has that value.
::: NOTIFY Unstacking
     Sends a Channel 13 Notify message to http://www-bd.fnal.gov/cgi-
     bin/notify_mes.pl?ch13=text.
::: EVENT 91 DISABLE
     Disabled the TCLK event $91 (Accumulator unstuck cycle reset).
::: WAIT_FOR SECS 6
::: CTLIT_DEVICE A:R1LLMR ON
     ARF1 phase lock to extract 53 MHz parameter is turned on.
```

```
::: CTLIT_DEVICE A:R1LLFP OFF
     ARF1 frequency program (curves) select parameter is turned off.
::: SET_DEVICE A:CNFRQU +=5.0
     Increment A:CNFRQU (Accumulator Center Revolution Frequency unstacking)
     by 5 Hz.
::: SET_DEVICE A:R2DDS1 A:CNFRQU
     Sets A:R2DDS1 (Accumulator LLRF Synth #1/h) to A:CNFRQU (Accumulator
     Center Revolution Frequency unstacking).
::: SET_DEVICE I:D5CQR1 =99
     Sets A:R2DDS1 (Accumulator LLRF Synth #1/h) to A:CNFRQU (Accumulator
     Center Revolution Frequency unstacking).
::: WAIT_FOR EVENT 94
     Wait for TCLK event $94 (Accumulator injected pbar synch).
     CATV PBAR #28 during a typical unstacking event.
      CATV PBAR #16 during a typical unstacking event.
      CATV PBAR #18 during a typical unstacking event.
                                                         This is the
      Accumulator Gap Monitor (Jello Display).
```



::: NOTIFY Inject Phars

```
Sends a Channel 13 Notify message to http://www-bd.fnal.gov/cgi-
           bin/notify_mes.pl?ch13=text.
     ::: SETIT_DEVICE V:PSHOOT =1
           Sets state V:PSHOOT = 1 (not ready for transfer), and then checks that
           it is at that value.
     ::: SETIT_DEVICE A:VSARST =1
           Sets VSA #1 Restart control parameter to 1 (Restart measurement).
     ::: WAIT_DEVICE A:VSARST
           Waits for A: VSARST to be zero.
     ::: SET_DEVICE A:CNFRQU A:CENFRQ
           Sets A:CNFRQU (Accumulator Center Revolution Frequency unstacking)
           equal to A:CENFRQ (Accumulator center revolution frequency).
     ::: SET_DEVICE A:CNFRQU +=5.0
           Increment A: CNFRQU (Accumulator Center Revolution Frequency unstacking)
           by 5 Hz.
     ::: SET DEVICE A:R2DDS1 A:CNFRQU
           Sets A:R2DDS1 (Accumulator LLRF Synth #1/h) to A:CNFRQU (Accumulator
           Center Revolution Frequency unstacking).
     ::: CUSTOM COOL_GAIN
           Sets core cooling PIN attenuators to values obeying an equation mult(i)
            *(A:IBEAMB) +offset(i). The constants "offset" and "mult" are stored in
           a table maintained by the AD\Pbar department. Custom cooling gain
           usually undershoots cooling power for larger stacks.
     ::: WAIT FOR SECS 5
     ::: COPY_SCREEN 0 SA
     ::: SHOT_LOG IMAGE
           Adds the following plot into the Pbar portion of the shot scapbook at
           http://www-bd.fnal.gov/cgi-mach/machlog.pl?nb=scrap03. This plot
           represents the unstacking transfer efficiencies, and is repeated for
           all nine transfers.
     ::: SETIT DEVICE A:VSARST =4
           Sets A:VSARST (VSA #1 Restart Control) to 4 (center 4-8 GHz arrays on
           A:CENFRQ).
     ::: SETIT DEVICE A:R4RDY =0
           Sets A:R4RDY (ARF4 ready to run) to be equal to zero.
::: LOOP END:LOAD PBARS
     End of the Pbar extraction loop. After the loop has been executed nine
     times, the aggregate continues below.
::: INSTRUCT 256
```

```
If there have been no problems loading the Tevatron with Pbars,
      you have gotten to this point and can continue. If additional shots
      to the Tevatron are needed, move up to the step
            LOOP BEGIN: LOAD PBARS 9 and play out the Sequencer from there
      until the necessary number of shots are completed. If only a single
      shot is needed, simply begin at the line below WAIT_DEVICE V:TSHOOT.
      Do Not use this aggregate for Recycler shots. Play this one out and
      move to Recycler Unstack & Transfer.
                  Interrupt anywhere in this box to continue.
::: EVENT 7A DISABLE
     Disabled TCLK event $7A (Main Injector BPM write profile memory).
::: EVENT E1 DISABLE
     Disabled TCLK event $E1 (Recycler Pbars from Accumulator reset).
::: EVENT 9A DISABLE
     Disabled TCLK event $9A (Accumulator Pbar to Main Injector transfer prep).
::: EVENT 94 DISABLE
     Disabled TCLK event $94 (Accumulator injected Pbar synch).
::: CTLIT_DEVICE A:R1LLFP ON
     ARF1 frequency program (curves) select parameter is turned on.
::: CTLIT_DEVICE A:R1LLH2 OFF
     ARF1 phase lock to h=2 system is turned off.
::: CTLIT_DEVICE A:R1LLMR OFF
     ARF1 phase lock to extract 53 MHz is turned off.
::: CTLIT DEVICE A:R4HLSC OFF
     Turns off ARF4 HLRF.
::: CTLIT DEVICE A:R4LLAM OFF
     Turns off ARF4 amplitude control parameter.
::: CTLIT_DEVICE A:EKIK OFF
     Turns off the Accumulator extraction kicker.
::: CTLIT_DEVICE A:EKIKQ OFF
     Turns off the Accumulator extraction kicker.
::: CHECK_DEVICE A:R1LLPS SAVE_SET .
     Reads and saves the present setting of A:R1LLPS (ARF1 VCO phase control) in
     degrees.
::: CHECK_DEVICE A:R4MIPS SAVE_SET .
     Reads and saves A:R4MIPS (ARF4 Main Injector phase setpoint) in degrees.
::: SHOT_LOG Image
     Adds the following plot into the Pbar portion of the shot scapbook at
     http://www-bd.fnal.gov/cgi-mach/machlog.pl?nb=scrap03. This plot represents
      the Accumulator RF unstacking parameters.
::: SETIT_DEVICE A:SHTNUM =0
     Resets the Pbar Transfer Series shot number to zero.
::: SETIT_DEVICE V:SETPBT =5
     Sets state V:SETPBT to 5.
ok INSTRUCT 258
Collider Aggregate: Run II Load Collider Pbars has been
completed.
Next Aggregate: Run II Revert to Stack Lattice
How to get back to stacking form here: Finish this aggregate and
```

then run both the $\underline{\text{Run II Revert to Stack Lattice}}$ and the $\underline{\text{Run II}}$ $\underline{\text{Return to Stacking}}$ aggregates.