Visit to BNL 17-19 Nov 2008


C. Schmidt, D. Bollinger, C.Y. Tan


BNL People


- James Alessi
- Vinnie Lodestro
- Deepak Raparia (Linac group leader)

RFQ

- 200MHz structure
- About 1 m long.
- Input energy is 35KeV
- Output energy is 750KeV
- Designed/built about 20 years ago by John Staples.
- Interesting note: There are parts of the BNL RFQ which FNAL cancelled.







The Source

- Takes about 1 shift (8 hrs) to start up a new Hsource. (c.f. FNAL which takes about 2-3 days).
- The source lasts for at least 9 months.
- From empirical experiment, the output of the Hsource is a combination of gas flow, cesium and magnetic field.

The source con't


- Source has no heater, bnl experience shows that it made little difference
- •Output of source could vary by a few milliamps, the RFQ acts like a beam current "filter" (what gets captured in the RF bucket), so the source has a lot of headroom. This means that even if the source starts to trail off, the output of the RFQ remains constant.
- •BNL source uses a hand made H2 valve that uses a cap discharge to open. The valve is very fast (rise and fall times) and is not subjected to the full heat of the source.
- •Like FNAL, BNL tried several variations of asymmetric cathodes and found little or no improvement on source operation.
- BNL operates their cesium boiler at ≤ 100 C whereas FNAL H- & I- operate at ~ 140 C. The HINS source has been operated to ≤ 100 C.
- BNL uses a permanent magnet for their source. The H- and I- sources use an electromagnet. The HINS source will use a permanent magnet with a small trim electromagnet (~20 Gauss).
- BNL experience is that a lower arc current \Rightarrow cleaner source. The H- and I- sources run at \sim 50A. The HINS source has ran at \sim 10A.

The source in the cube





3000 1/s pump

Source in the Cube




Source disassembled








Extractor




The Anode cover plate



How the Anode cover is Mounted



Another View




Extractor is connected to the Anode



Pump at Source

- 3000 Litre/second pump.
- ~10 in pipe.
- Vacuum in the low 1e-6 torr.





Conclusion

- To test the hypothesis that the reason why our source performs differently from the BNL ones, we think that the new HINS source might give us the answer because
 - The new source for HINS will have much better vacuum than the operational source.
 - HINS source will also have a lower arc current (~ 10A) compared to ~50A.
- We want to see if the HINS source can output 80mA continuously for 6 to 9 months.